

Philips Drip tray cover

Metal

CRP460

# To hold your cups during brewing

Tired of your old and dull looking drip tray cover? Buy a new drip tray cover and enjoy the look of you Senseo® coffee machine as if it were new.

### Ease of using Philips spare parts

· Renew your product with original Philips parts



## **Specifications**

Replaceable part
• Fits product types: HD7825/30, HD7825/50, HD7825/60, HD7825/62, HD7825/70, HD7825/

80, HD7827/50, HD7827/52, HD7828/10, HD7835/10

## CRP460/01

## Highlights

### Easy replacement

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality and 1:1 exchange.



Issue date 2011-10-20

Version: 1.0.1

© 2011 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com